


GEAR CASINGS

1. Bell housing and clutch release assembly
2. Oil pump assembly
3. Front bearing plate
4. Main gear case
5. Oil filter assembly
6. Gear change lever assembly
7. Extension housing



ST1319M