



N293

**CIRCUIT DIAGRAM LEGEND**

- |                                              |                                            |                                              |
|----------------------------------------------|--------------------------------------------|----------------------------------------------|
| 1. Auxiliary driving lamps                   | 29. L.H. indicator warning light           | 57. Interior light                           |
| 2. Cigar illumination                        | 30. R.H. indicator warning light           | 58. Trailer socket connection                |
| 3. Clock illumination                        | 31. Voltage stabiliser                     | 59. Shuttle valve                            |
| 4. Auxiliary, instrument, illumination, feet | 32. Water temperature gauge                | 60. Windscreen wiper and washer switch       |
| 5. L.H. front side lamp                      | 33. Fuel gauge                             | 61. Oil pressure gauge                       |
| 6. R.H. front side lamp                      | 34. Lighting switch                        | 62. Pre-engaged starter, type M45            |
| 7. L.H. rear marker lamp (NADA only)         | 35. Indicator, headlamp dip & horn switch  | 63. Coil                                     |
| 8. L.H. rear tail lamp                       | 36. Clock                                  | 64. Battery, type C9                         |
| 9. Number plate illumination lamp            | 37. Differential lock warning light        | 65. Relay                                    |
| 10. Number plate illumination lamp           | 38. Differential lock warning light switch | 66. Heated rear screen                       |
| 11. R.H. rear tail lamp                      | 39. Choke warning light                    | 67. Heated rear screen switch                |
| 12. R.H. rear marker lamp (NADA only)        | 40. Oil pressure warning light             | 68. Distributor                              |
| 13. R.H. headlamp, main                      | 41. Ignition warning light                 | 69. Inspection sockets                       |
| 14. L.H. headlamp, main                      | 42. Brake warning light                    | 70. Courtesy light switch                    |
| 15. R.H. headlamp, dip                       | 43. Fuel level warning light               | 71. Interior light switch                    |
| 16. L.H. headlamp, dip                       | 44. Radio                                  | 72. Courtesy light switch                    |
| 17. Horns                                    | 45. Cigar lighter                          | 73. Handbrake switch                         |
| 18. L.H. rear indicator                      | 46. Hazard warning unit                    | 74. Oil pressure switch                      |
| 19. L.H. front indicator                     | 47. Hazard warning switch                  | 75. Choke thermostat                         |
| 20. R.H. front indicator                     | 48. Alternator, type 16 ACR                | 76. Fuel gauge unit                          |
| 21. R.H. rear indicator                      | 49. Starting relay                         | 77. Water temperature transmitter            |
| 22. Indicator unit                           | 50. Ignition switch and steering lock      | 78. Screen washer motor                      |
| 23. Auxiliary driving lamp switch            | 51. Fuse (1)                               | 79. Windscreen wiper motor, type 17W 2—speed |
| 24. Trailer warning light                    | 52. Fuse (2)                               | 80. Heater motor                             |
| 25. Instrument illumination                  | 53. Fuse (3)                               | 81. Oil pressure transmitter                 |
| 26. Instrument illumination                  | 54. Choke switch                           | 82. Stop light, R.H.                         |
| 27. Panel light switch                       | 55. Stop lamp switch                       | 83. Stop light, L.H.                         |
| 28. Main beam warning light                  | 56. Reverse light switch                   | 84. Reversing light, R.H.                    |
|                                              |                                            | 85. Reversing light, L.H.                    |

- SNAP CONNECTORS
- CONNECTIONS VIA PLUG & SOCKET
- EARTH CONNECTIONS VIA CABLES
- EUREKA RESISTANCE WIRE

**CABLE COLOUR CODE**

- |           |          |
|-----------|----------|
| G= Green  | U= Blue  |
| O= Orange | B= Black |
| S= Slate  | R= Red   |
| K= Pink   | W= White |

Note:  
All circuits shown dotted are additional extras. When cables have two colour code letters, the first denotes the main and the latter the tracer.